



Fittings Mod. 5150 and Mod. 5180



DIMENSIONS					
Mod.	A2	∅	H	L	SW
5150 1/8	G1/8	5	6	26	13
5150 1/4	G1/4	5	8	28,5	17
5180 1/4	G1/4	7	8	33	17
5180 3/8	G3/8	7	9	34	19
5180 1/2	G1/2	7	10	35,5	24




Fittings Mod. 5350 and Mod. 5380



DIMENSIONS				
Mod.	B2	∅	L	SW
5350 1/8	G1/8	5	25,5	13
5350 1/4	G1/4	5	27,5	17
5380 1/4	G1/4	7	31,5	17
5380 3/8	G3/8	7	32,5	19
5380 1/2	G1/2	7	36,5	24



Fittings Mod. 5450 and Mod. 5480




DIMENSIONS							
Mod.	Tube	∅	C1	I	L	SW	SW1
5450 6/4	6/4	5	3	15	35	12	12
5450 8/6	8/6	5	5	15	35	13	14
5480 8/6	8/6	7	5	15	39,5	14	14
5480 10/8	10/8	7	6,5	16,5	41,5	17	16



Fittings Mod. 5650 and Mod. 5680

Dimension "N" = tube internal diameter



DIMENSIONS					
Mod.	N	∅	C1	I	L
5650 06	6	5	3	20	35,5
5650 09	9	5	5	20	35,5
5680 06	6	7	3	20	40
5680 09	9	7	5	20	40
5680 12	12	7	7	20	40

