


Cover plate for unused positions

The following is supplied:
1x seal
4x screws




Mod.
901-TP

Mounting example



Separation tap lines 1 - 3 - 5 to be used with manifold type 901-C1A and 902-C2A




Mod.
901-C1A/TP
902-C2A/TP

Separation joint



Separation joint to be used with manifold type 901N




1 - 3 - 5 closed

Mod.
901-N1A/T

Separation joint



Separation joint to be used with manifold type 901N.
P plugged.



1 closed

Mod.
901-N1A/TP